



- Step 1. Bolt angle brackets to backside of LED display
 Step 2. Cut steel angle to appropriate length and weld to poles
 -Take care to measure spacing so that the LED brackets will rest onto the steel angles after welding.
 -Steel Angle should be 2.5" x 2.5" x 1/4" wall minimum,
 -Also be sure that the steel angles are level.
 Step 3. Drill holes in steel angles matching hole patterns on LED brackets
 Step 4. Gently seat the LED display onto the steel angle and bolt together.
 -Washers and locking washers are necessary.

