



Because every installation is different and unique power cable is left inside the cabinet until ready for installation and wiring by licenced Electrical Contractor. This process eliminates installation or placement issues.

Simply drill into the cabinet (sides, top, bottom or back) install a basic Bell box and make your connections.

Steps:

- Power cables rest inside the cabinet
- Locate best access point as not to interfere with installation of sign cabinet and easily accessible for service and maintenance.
- Drill hole to mate with Bell box and make secure watertight seal.
- Run cable into Bell box and make typical connections.

All work must be performed by Licensed Electrical Contractor.
Proper grounding and load ratings applied.
Local disconnect necessary per Electrical Code.

Repeat directions for network cable connection.