


## WIFI ROUTER CONFIGURATION AND INSTALL



**Wifi Router:  
D-Link N-300  
Wireless N Gigabit Router  
DIR-655**



**Antenna / Cable**

### **Instructions:**

#### **1) Configure the Wifi Router**

- power up router**
- connect laptop to router port 1**
- change IP in laptop to 192.168.0.66**
- log into your router by entering 192.168.0.1 in internet explorer**
- change the router IP address to 192.168.1.1**
- change IP in laptop to 192.168.1.66**
- log into your router by entering 192.168.1.1 in internet explorer**
- change the router name to “MaxxLite LED”**
- apply maxxliteled01 for a password**

#### **2) Provide power outlet inside the sign cabinet to plug in the Wifi Router.**

#### **3) Place Wifi router inside the sign cabinet and plug in the power**

#### **4) Connect the controller to the Wifi router port 1 (use network cable that came with router)**

#### **5) In laptop Wifi networks, locate and connect to MaxxLite LED, enter password as requested.**

#### **6) You are ready to communicate and upload your content**